

Product Specification

Product model: **DP19**

Product type: **Disposables**

Version	V1	Effective Date	4/30/2020
R&D Dept.	0132	Page	4

1. Dimension (Picture and Description)



Description: Disposable vape pen

Appearance: There is no scratches, cracks, stains, uneven colors, unclear logos, and fades on the appearance of this product.

2. Features

- Inhale Activated
- Dual Protection Chips Built-In
- Flexible Production Process
- Highly Customizable in Mini Form



3. Main Technical Parameter

Specifications	
Tank volume	0.5ml
Resistance	1.2±0.2Ω
Aperture size	1.6mm
Aperture number	4
Battery capacity	90mAh
Heating core material	Nichrome
Oil drawing material	Non-woven
Tank material	PCTG
Output voltage	3.3V (±0.15)
Charging voltage	4.75V-5.25V
Battery life	300 cycles
Storage temperature	23°C±5°C
Working temperature	-10°C ~ +50°C
Dimension	Ø9.2x88mm
Weight	10.96g

4. How to Use

Inhale activated

5. Oil Filling

1) Fill the tank with your favorite oil.

Gently put the syringe between the airway and the outer wall of the cartridge and fill the cartridge with oil at a proper speed.



2) Press the mouthpiece into tank with a special jig within 2 minutes.

We highly recommend to use capping machine to press the mouthpiece.

Notes:

- ▲ *Do not inject the oil into the airway!*
- ▲ *Do not top off the tank with oil.*

6. Storage

- The storage temperature is 23 ± 5 °C and the humidity is $50 \pm 10\%$ RH.
- Place in a cool, dark and ventilated place.
- Keep the disposable sealed storage and avoid direct sunlight.
- The storage period should not be too long, so as not to exceed the shelf life of oil.

7. Notes

- ▲ Pay attention to the shelf life of filled oil.
- ▲ Handle the glass cartridge with care. Do not crush or throw the cartridge.